

# ADJUSTMENTS FOR FRONT MCD SHADE

The MCD front shade is great for both privacy and as a sun visor when driving.

The “**sun visor**” position should be just above eye-level while sitting as you would be while driving.

The “**privacy**” position should be all the way down to the bottom of the inside of the windshield plus a little “slack”.

The “full up” position should be about 1 inch from the roller.

You will need to locate two buttons:

1. The **Learning** button. This should be at the end of a short wire on the left side of the shade.
2. The **UP/DOWN** button. This should be in the center console of the dash (below radio)

Most up-to-date version with links here: <https://thoreuro.com/tips.html#mcdadjust>

## ADJUSTING THE FRONT MCD SHADE

- ☐ Using the UP/DOWN button, put shade it the up-most position.
- ☐ Turn ignition key ON (engine can be running or not).
- ☐ Press and hold Learning button while pressing the DOWN button.
- ☐ Release Learning button when you hear a beep – keep holding the DOWN button.
- ☐ Keep holding the DOWN button until the shade is close to the desired “sun visor” position.
- ☐ Nudge the DOWN button (ONLY NUDGE – do not press and hold!) until the shade is in the precise “sun visor” position.
- ☐ Press and hold the UP button until the shade is just below desired “full up” position.
- ☐ Nudge the UP button (ONLY NUDGE – do not press and hold!) until the shade is in the precise “full up” position.
- ☐ Press DOWN button until you hear a beep to lock in the ENGINE ON positions.
- ☐ Press UP button until the shade is in the “full up” position.
- ☐ Turn ignition key OFF.
- ☐ Press and hold Learning button while pressing the DOWN button.
- ☐ Release Learning button when you hear a beep – keep holding the DOWN button.
- ☐ Keep holding the DOWN button until the shade is close to the desired “privacy” position.
- ☐ Nudge the DOWN button (ONLY NUDGE – do not press and hold!) until the shade is in the precise “privacy” position.
- ☐ Press and hold the UP button until the shade is just below desired “full up” position.
- ☐ Nudge the UP button (ONLY NUDGE – do not press and hold!) until the shade is in the precise “full up” position.
- ☐ Press DOWN button until you hear a beep to lock in the ENGINE OFF positions.
- ☐ Press UP button until the shade is in the “full up” position.
- ☐ Test all 4 limits and you’re done!

